


## **SOLDERING TIPS**


It is important to make a good solder joint at each connection point. A cold solder joint is a connection that may look connected but is actually disconnected or intermittently connected. (A cold solder joint can keep your project from working.)

Follow these tips to make a good solder joint. *Take your time with each connection and make sure that all components are connected and will remain connected if your project is bumped or shaken.*


1. Bend the component lead or wire ending and wrap it around the connection point.
  - Make sure it is not too close to a neighboring component which could cause an unintended connection.
2. Wrap the component lead so that it can hold itself to the connection point.
3. Touch the soldering iron to both the component lead and the connection point allowing both to warm up just before applying the solder to them.
4. Be sure to adequately cover both component lead and connection point with melted solder.
  - Remove the soldering iron from your work and allow the solder joint to cool. (The solder joint should be shiny and smooth after solidifying.)
  - Cut off any excess wire or component leads with cutting pliers.
  - Clean the soldering iron's tip by wiping it across the wet sponge again after making the solder joint.




1. Bend the component lead and wrap it around the connection point.



2. Wrap the component lead so that it can hold itself to the connection point.




3. Heat up both component lead and connection point with the soldering iron.




4. Apply solder to both component lead and connection point.


### **De-Soldering Tip**



1. Heat up old solder joint with the soldering iron.



2. Apply fresh solder to mix in with old solder joint



3. Use a de-soldering tool to remove the old solder joint while it is heated.